

## **Chili Dip**

**Heidi Leonard, Branch Manager, West Springfield, MA**

Ingredients:

- 1 can of Hormel Turkey no bean Chili
- 1 bar of softened Cream Cheese
- 1.5 cup of shredded Mexican cheese

Take a pie plate and spread the softened cream cheese on the bottom. Put the turkey no bean chili over the cream cheese. Sprinkled the cheese on top. Cover and put in the microwave for 3 minutes.

Don't tell anyone its Turkey they won't know.